

# Mobrey Submersion Shield for the MSP900SH and MSP900FH




## About this guide

This guide provides instructions for fitting a Mobrey Submersion Shield (part number MSP-SUB2) which is an optional accessory for the Mobrey MSP900SH Level and MSP900FH Flow transmitters.

It does not provide installation instructions for the transmitters (or their optional accessories). Refer to the MSP900SH or MSP900FH installation manuals for detailed instructions.

Product data sheets, reference manuals, and quick-start guides are available electronically on [www.mobrey.com](http://www.mobrey.com).

**Figure 1. Example application with a submersion shield fitted**



- A. Mobrey MSP900SH Level or MSP900FH Flow Transmitter
- B. Mobrey Submersion Shield (*part number MSP-SUB2*)
- C. Mobrey Head Verification Device (*part number MSP-HVD*)
- D. Conduit (*not supplied*)
- E. Mobrey Conduit Adaptor Boss,
  - 1-in. BSP female to M20 x 1.5 female (*part number 03100-1005-0001*) or
  - 1-in. NPT female to 1½-in. NPT female (*part number 03100-1005-0002*)

## Mobrey MSP900SH/MSP900FH Submersion Shield


The Mobrey Submersion Shield (MSP-SUB2) is recommended for installations, e.g. wet wells, where a MSP900SH/MSP900FH transmitter may be at risk of being flooded.

It is easily fitted over the transducer cup, but requires the transmitter to be kept firmly vertical so that flood water causes an air pocket and keeps the transmitter face clear. The transmitter can then function normally when the flood water subsides.

Figure 1 on page 2 shows an example application with the submersion shield already fitted to a Mobrey MSP900SH/MSP900FH transmitter, which is then mounted on a Mobrey Head Verification Device.

---

**Figure 2. Features of the Mobrey Submersion Shield**



- A. PVC Submersion Shield (Medium Grey)
- B. Silicone O-ring (Red)
- C. Fluoroelastomer (FKM) O-ring (Dark Grey)
- D. Foam (PVC/NITRILE)

---

### WARNING

**Failure to follow these installation guidelines could result in death or serious injury**

- Make sure only qualified personnel perform the installation
- Use the equipment only as specified in this manual. Failure to do so may impair the protection provided by the equipment

**Electrical shock could cause death or serious injury**

- Make sure the main power to the transmitter is off and the lines to any other external power source are disconnected or not powered whilst installing the submersion shield
-

## Fitting the submersion shield

### Step 1: Check the transmitter mounting

The transmitter mounting must ensure that the transmitter is firmly kept in place, and ideally at 90 degrees to the liquid surface. This is essential for an air pocket to be formed at the base of the shield as flood water rises and passes it.

### Step 2: Lubricate both O-rings before fitting the shield


A suitable lubricant such as Dow Corning MS4 silicone grease may be used. If this is not available, a suitable water-based lubricant or liquid detergent may be used.

### Step 3: Fit the submersion shield

#### Follow this procedure:

1. Align the shield opening with the transducer cup, ensuring that the red O-ring is above the grey O-ring (Figure 3, left image).
2. Hold the transmitter and firmly push the shield upwards onto the transducer cup, until the red O-ring is on the transducer cup (Figure 3, middle image).
3. Continue pushing the shield upwards firmly until the red O-ring engages with the recess on the transducer cup (Figure 3, right image).

**Figure 3. Visual help for fitting the submersion shield**



A. Transducer Cup

B. Recess on Transducer Cup


## Removing the submersion shield

This is only necessary for occasional cleaning or inspection in the event of contamination from flood water.

### Follow this procedure:

1. Holding the transmitter, pull the shield downwards firmly until the red O-ring is released from the recess on the transducer cup (Figure 4).
2. Continue to pull the shield downwards until it is free from the transducer cup.
3. Inspect the O-rings inside the shield for any signs of damage, and replace if necessary. Contact Mobrey for how to get replacements.

**Figure 4. Visual help for removing the submersion shield**



A. Transducer Cup

B. Recess on Transducer Cup





**Emerson Process Management  
Mobrey Ltd.**

158 Edinburgh Avenue  
Slough, Berks, SL1 4UE, UK  
Tel: +44 (0)1753 756600  
Fax: +44 (0)1753 823589  
[www.mobrey.com](http://www.mobrey.com)

**Emerson Process Management  
Rosemount Measurement**

8200 Market Boulevard  
Chanhassen, MN 55317 USA  
T (USA) 1 800 999 9307  
T (Intl) +1 952 906 8888  
F +1 952 906 8889

© 2012 Mobrey Ltd. All rights reserved. All marks property of owner.  
The Emerson logo is a trade mark and service mark of Emerson Electric Co.  
Mobrey and the Mobrey logotype are registered trademarks of Mobrey Ltd.  
Rosemount and the Rosemount logotype are registered trademarks of Rosemount Inc.